HOW TO USE

Dyno








Preheating

2 clicks on the button to activate 15s preheating 1 click on the button to stop preheating



Adjust Airflow

slide the switch to the right or left fully open fine-tune close



Button Activated to Use

simply hold down the button as you draw from the mouthpiece

