

Filling and Capping Instructions

Zirconia Cartridge



Insert a blunt tip needle into the space between the center airway tube and the inner wall of the cartridge. We recommend an oil temperature range of 90°F-130°F when filling.

Caution:

- Do not allow oil to enter the center airway tube.
 - Do not overfill. If you overfill a cartridge, fluid will be forced through the atomizer and leak out of the bottom of the cartridge when the mouthpiece is capped.
-



Immediately after filling, press on the mouthpiece by hand punch until it is fully seated.

Caution:

- The cartridge must be upright and centered with the mouthpiece when pressing down.
 - Failure to capping immediately after filling may cause leakage.
-



Allow your cartridge to stand for at least 30 minutes.

During this time, oil is priming the atomizer. The rate that the atomizer saturates is dependent upon the viscosity of the oil. More viscous oils will require more time.

