



## Maxyl Dou 1.0ml + 1.0ml

### Dual Chamber AIO Disposable

EmPower Your Oil & Brand to be the BEST.

Customized Device Settings for the BEST Oil Performance with Device Counterfeit Authentication.

## Dimension (Picture and Description)



Dimensions: 68.8 x 34 x 17mm

## Features

- Draw Activated
- Two Coils, Two Tanks
- Two Flavors & Blend Flavor
- Hcore® Ceramic Heating Element
- Pure Flavor, Large Clouds
- Smart Digital Display
- Fingerprint Touch Sensitive Controls
- Fun Blinker Challenge
- Intuitive Operation

1 tap on Fingerprint Sensor to check battery level and flavor mode

3 taps to switch between flavors: The screen displays a left or right arrow showing your active flavor selection. Both arrows illuminate when in blend mode.

- Short Circuit Protection

Short circuit protection is triggered when the device is enabled. LED indicator flashes red 3 times and screen flashes "SO" synchronously.

- Overload Protection

Overload protection is triggered when the current rises above a limit. LED indicator flashes red 3 times and screen flashes "SO" synchronously.

- Out of Power

If the battery is too low, LED indicator flashes red 10 times, and screen flashes "0%" synchronously. When the battery is completely depleted, there is no response.

- Charging

Charging Mode: Both arrows stay on; screen cycles between spinning and battery percentage.

- Full Charge: Both arrows stay on; display reads 100%.

- Accidental Touch Protection

The device will enter protection mode if it outputs continuously for 35 seconds within 40 seconds, or triggers 40 times within 40 seconds. The protection mode lasts for 30 seconds. If the protection is triggered again during this period, the 30-second timer will restart. Under protection mode, the LED indicator will continuously flash, screen flashes "1" (35 seconds) or "2" (40 times) synchronously, and the device will be unresponsive.

## Main Technical Parameter

Item	Parameter
Dimension	68.8 x 34 x 17mm
Volume	2 x 1.0ml
Heating Core Material	Ceramic
Mouthpiece Material	PC
Tank Type	PCTG
Center Post	SUS316L

Aperture Inlet	2 x 4 x Ø1.6mm
Resistance	0.7Ω
Weight	28.4g
Activation	Draw Activated
Battery Capacity	350mAh
Battery Housing	PC
Output Power	Flavor A: 8.5-8.0-8.0-7.5-7-7-7-7-7W Flavor B: 8.5-8.0-8.0-7.5-7-7-7-7-7W Mix Mode: 14-13-12.5-12-12-12-12-12-12W
Charging Voltage	4.5-5.5V
Storage Temperature	23 ± 5°C
Working Temperature	-10°C ~ +50°C
Charge Port	Type-C

## Customized Services



- Color: Custom the color of mouthpiece and device, any pantone accepted
- Finishing: Spray painting, rubber coating, UV printing, etc.
- Logo: Screen Printing (Single Color) / UV Printing (2 or More Color)

## Filling Guide

### 1. Fill the tank with your cannabis oil.

Gently put the syringe into one of the tanks and fill the tank with oil at a proper speed, then fill the other one.

- *Do not allow oil to enter the 4 airway holes! (Two on each side, and the two in the middle are oil inlet holes.)*
- *Do not top off the tank with oil.*
- *While filling oil, avoid dropping oil onto the shell to prevent chemical reactions. If so, please wipe it off immediately.*

### 2. Press on the mouthpiece immediately after filling!

- *Failure to insert the mouthpiece immediately after filling may cause leakage.*
- *We highly recommend using a capping machine or hand punch to press the mouthpiece.*

## Storage & Care

1. The storage temperature is  $23 \pm 5^{\circ}\text{C}$  and the humidity is  $50 \pm 10\%$  RH.
2. Place in a cool, dark and ventilated place.
3. Keep the disposable sealed storage and avoid direct sunlight.

## Notification

1. Press on the mouthpiece immediately after filling.
2. Do not blow on the bottom to activate the device.
3. Pay attention to the shelf life of filled oil.
4. Handle the product with care, no dropping or twisting.