



Dual Tank Post-free AIO

0.5+0.5ml | 1.0+1.0ml | 1.5+1.5ml
KC-D38/M20

Dimension (Picture and Description)



Features

- Tank Capacity: 0.5+0.5ml | 1.0+1.0ml | 1.5+1.5ml
- Battery Capacity: 400mAh
- Resistance: 1.55ohm
- Post-free Design
- LCD Screen

Main Technical Parameter

Item	Parameter
Dimension	71.5 x 35 x 15(mm)
Tank Volume	0.5+0.5ml 1.0+1.0ml 1.5+1.5ml
Resistance	1.55Ω
Battery Capacity	400mAh
Heating Core Material	Ceramic
Tank Material	PCTG
Center Post	Post-free
Battery Life	300 Cycles
Storage Temperature	23°C±5°C
Working Temperature	-10°C~+50°C

How to Use

- Inhale activated.

Filling Guide

1. Fill the tank with your cannabis oil.

Gently put the syringe between the airway and the outer wall of the oil tank and fill the tank with oil at a proper speed.

- *Do not allow oil to enter the center airway!*
- *Do not top off the tank with oil.*
- *While filling oil, avoid dropping oil onto the shell to prevent chemical reactions. If so, please wipe it off immediately.*

2. Press the mouthpiece into tank with a special jig within 3 minutes.

- *Do not inject the oil into the airway!*
- *Do not top off the tank with oil.*
- *While filling oil, avoid dropping oil onto the PC shell to prevent chemical reactions. If so, please wipe it off immediately.*

Storage

1. The storage temperature is $23 \pm 5^{\circ}\text{C}$ and the humidity is $50 \pm 10\%$ RH.
2. Place in a cool, dark and ventilated place.
3. Keep the disposable sealed storage and avoid direct sunlight.
4. The storage period should not be too long, so as not to exceed the shelf life of oil.

Notification

1. Pay attention to the shelf life of filled oil.
2. Handle the product with care. Do not throw, or twist the product.